


## L- Clip Installation Instructions

1. Determine the desired height from floor ro bottom of board, draw a line (Line One) and attach L-Clip to wall, making certain the bottom of clips are on the line when in full down postition.

If board is to be mounted to a "stud" wall, it is best to mount the L-Clip directly into the studs. If they can be found. Most wall studs are spaced 16" apart, and it is best to mount an L-clip at every other stud. On walls other than stud walls, place one L-Clip approximately 6" from each end and evenly space the others 2 or 3 feet apart using plastic anchors mounted into wall to hold screws securely.

- 2. Set board on bottom clips and mark a reference line (Line Two) on the wall along top of board as a guide for positioning top clips.
- 3. The L-clips along top of board should be positioned so that when board is in place, the clips can be lapped down on top of frame.
- 4. There is a screw hole in the short leg of each L-clip. Hold the board firmly to the wall and mark the frame at each screw hole. Drill 1/16" holes into the frame molding, top and bottom, and screw self-tapping screws through the L-Clips into the molding to hold board firmly in place.



Eagle Scoreboard Systems
Golfscoring.com | (208) 503-6482